



ASCEND ACOUSTICS, INC. www.ascendacoustics.com
1842 W 169th St Suite B, Gardena, CA 90247 (310) 719-9786
Email: custservice@ascendacoustics.com Fax (310) 388-1500

Stand Assembly

Step 1: Attach the base of the stand to the pedestal using (4) of the included 1 5/8" wood screws. These wood screws are located in one of the plastic bags (8 in total, 4 per stand).

Step 2: Attach (4) of the isolation pads to each corner of the top of the pedestal. These pads are meant to absorb resonance between the speaker and the stand. There are (8) pads in total, (4) for each pedestal, these pads are located in the same bag as the wood screws.

Step 3: Screw in the (4) spiked feet into the underside of the base of the stand. There are 8-spiked feet in total (4 per base). The discs included in the spiked feet bag are floor protectors and are designed to go underneath the spiked feet if you are using the stands on flooring other than carpet. Use of the spiked feet is optional but recommended. Note: There is 1 nut for each spiked foot. This nut must be threaded onto the spiked foot before screwing the foot into place. It is used to secure the spike into place (by tightening it towards the base) once you have adjusted the spike to the height your desire.

Step 4: Place the CMT-340 on top of the stand so that the rear baffle of the speaker is flush to the rear baffle of the stand.

Step 5: You may now secure the speaker to the stand by using the included wooden brackets (2 in total, 1 per stand). These brackets use the short 1/4 - 20 machine screws also located in the bag with the wood screws (4 in total, 1 screw in the speaker, 1 screw into the pedestal base).

Step 6: Dim the lights, put in your favorite CD, get comfortable in your easy chair or couch and immerse yourself in your favorite music...